

EcoMaster Samostatné pneutlačítko kulaté

Slouží k ovládání drtiče kuchyňského odpadu



EAN: 8596220000811
20,04 €
16,70 € excluding VAT



EAN: 8596220000101
23,64 €
19,70 € excluding VAT



EAN: 8596220005120
23,64 €
19,70 € excluding VAT



EAN: 8596220012296
23,64 €
19,70 € excluding VAT

Variants

Shiny chrome

- Chrome-plated durable plastic. The universal best-selling button with a long lifespan.

Frosted stainless steel

- Full stainless steel button. Brushed sheet surface treatment - resistance to scratches and abrasions, etc. Suitable for gastronomic operations.

For simple, convenient, and at the same time safe operation of kitchen waste disposals. This option is the most commonly used as the disposal is turned on and off in conjunction with water, allowing the button to be placed in close proximity to the faucet.

Location: In the worktop or directly into the free areas of the sink.

Safety: The button meets all safety requirements. It is suitable for humid environments and can even be directly poured with water. In addition to controlling crushers, it is also used, for example, to activate jets in whirlpools and large hot tubs.

Function: The button does not directly give an electrical impulse, but by the pressure of compressed air through the hose, it switches the pneumatic mechanism inside the tire crusher, which operates the electrical micro switch separated by a diaphragm. The button and the waste crusher are connected only by an air hose.

Note: Necessary for controlling the crusher if no other method of switching on (e.g. rocker or wireless switch) is selected. The hose is ordered separately if needed.

Components included in the package:

- The body of the switch with an air bladder.
- Selected button cover

Parameters

Basic parameters

Model:	Glossy chrome plated / Matte stainless steel brushed
Use:	Air pressure switching - crushers, whirlpools, pools
Warranty:	2
Weight including packaging (kg):	0.3
Width of the packaging (cm):	21
Height of packaging (cm):	7
Depth of packaging (cm):	30


Technical parameters

Method of attachment / installation:	Downloading matrix
Button material:	Screwing, nut - plastic
Thread diameter.:	32 mm
The diameter of the cover around the button.:	Shiny chrome - 50 mm / Matte stainless steel - 46 mm
Thread length for fastening:	Shiny chrome, white, black - possible length for attachment 54 mm - meaning possible thickness of the board / Matt stainless steel - possible length for attachment 35 mm - meaning possible thickness of the board.



EcoMaster preuŕaĕitko

Model kuŕaĕitko: lesnĕj ohran, bĕlĕ, ĕernĕ



Model kuŕaĕitko: ruznĕj vĕrnĕ

